

GoPro Camera | Hero 3+ black edition | High Definition

HERO3+
BLACK EDITION

Smaller, lighter, mightier still.
Introducing the most advanced GoPro yet.



Features

Resolution	1080p (high definition)
Remote Control	Yes
Waterproof case and floaty handle	Yes

Included

GoPro Hero 3+ camera	1080p (high definition)
Waterproof case	Yes with floaty back door
Mounts	1 x floaty handle 1 x tripod mount 1 x rollbar mount 1 x flatplate mount 2 x standard GoPro connectors each with 2 x extenders.
Micro SD	1 x 64GB Micro SD Card 1 x MicroSD Card to SD Card Adaptor
Remote	Yes (1 x recharger cable and 1 x keyring)
USB	1 x Mini-USB to USB 1 x Mains plug to USB socket
Instruction Manual	2 x user manuals 1 x quick start guide)

SPECIAL INSTRUCTIONS

1. Recharge GoPro camera and remote control before use.
2. Read instructions provided.
3. Insert camera into waterproof case and close securely.
4. Use mounts or handle.
5. Record stills or film.
6. Copy files from camera after use – use cable or MicroSD Card to SD Card Adaptor.
7. If used in salt water, wash case and bolts in cold fresh water after use (do not wash the camera!)
8. Dry case and bolts before returning.
9. Copying of files and/or editing by Denmark Community Resource Centre is an additional service and additional cost.
10. *** Camera card will be formatted after returning to Denmark Community Resource Centre ***