

# DigiFrame EzyScan 5" Photo Scanner



**SD Card Slot**

**Independent Scanning Option**

**Photo Sizes: 2"x2" to 5" x 11.8"**

**Included: Photo Scanner, CD (Scan to PC), Sensor cleaning swab, roller cleaning tool, calibration chart, AC Adapter, USB Cable, 5" x 7" plastic sheath, 2GB USB Flash Drive.**